

MAXIMUS-3

JK WRANGLER

FRONT BUMPER HI-LIFT JACK MOUNT

(Fits JK Wrangler with OEM Factory Hard Rock Steel Bumper)

PART #: HR1025JM

INSTALLATION STEPS

Estimated Install Time: 30 Minutes

PLEASE MAKE SURE YOU READ AND UNDERSTAND THE ENTIRE INSTALLATION GUIDE BEFORE YOU START. WE EXPECT YOU TO HAVE BASIC MECHANICAL ABILITIES TO PERFORM THIS INSTALLATION.

WE RECOMMEND THAT YOU SEPARATE AND IDENTIFY ALL THE PARTS AND HARDWARE KITS YOU RECEIVED WITH YOUR SHIPMENT BEFORE YOU PROCEED.

Parts List:

Front Mount Hi-Lift Jack Mount Bracket L/R

Qty

2

Tools Required:

- ✓ Your Basic Hand Tools
- ✓ Allen Keys/Wrench Set

Hardware Kit

M8 x 30 Button Head - Stainless

4

M8 Washers - Stainless

4

M8 Flange Nuts

4



IMPORTANT

Follow these instructions precisely. Maximus-3 is not liable for any damage caused by improperly installed products. It is the purchaser's responsibility to ensure both the installation and maintenance are performed properly as set forth in this guide. We recommend using anti-size paste on all non-thread lock bolts.

INSTALLATION STEPS

1- INSTALL AS SHOWN IN THE PICTURES BELOW:

- A. Install Hi-Lift Jack mount brackets on the front bumper as shown below using the hardware supplied.
- B. Install your Hi-Lift Jack onto the studs on the brackets and tighten down with the thumb/wing nut.
- C. Make sure that the Hi-Lift Jack is secured before you drive off.



Your installation is complete. If you have questions regarding this installation, please contact us at customerservice@maximus-3.com, or call 248-6061745